

**SERO / QUB  
LED MODULE  
REPLACEMENT**

NULITE

## **WARNINGS:**

- Do not assemble continuous run on the ground and lift into place. Joints will distort and not create a tight fit. Joining hardware will have to be purchased and replaced.
- Risk of electrical shock or fire, disconnect power during installation or servicing. Read all instructions completely before starting installation. Install and wire in accordance to all national and local codes by a certified electrician. Fixture may be sharp, handle with care. Let fixture cool before maintenance.


## **AVERTISSEMENTS**

- Risque d'électrocution ou d'incendie. Déconnectez l'alimentation durant l'installation ou la maintenance. Lisez attentivement toutes les instructions avant de commencer toute installation. Faites installer et câbler selon les normes Nationales et Locales par un électricien certifié. Les installations peuvent être coupantes, à manipuler avec précaution. Laissez refroidir les installations avant une opération de maintenance.

## **ADVERTENCIA**

Riesgo de descarga eléctrica o un incendio, desconecte la alimentación durante la instalación o servicio. Leer todas las instrucciones completas antes de empezar la instalación. Instalar y cablear en acuerdo a las reglas nacionales y códigos locales por un electricista certificado. El accesorio puede estar agudo, agarre con cuidado de que el accesorio. Enfriar antes de mantenimiento.

## Shipment summary – Sero/Qub



Reference this part # on the top of the luminaire in the field and communicate the part # to your local Nulite sales agent in order to match the color temperature of the replacement module.

## SERO / QUB Replacement LED Module

Two Sizes:


A- L (47 3/4") x W(7/8") x H (5/8")

B- L (23 3/4") x W(7/8") x H (5/8")

# LED Module Replacement Instructions



## 1. Disconnect Power



## 2. Remove three Philips screws



# LED Module Replacement Instructions



**3. Gently Lift Off  
LED Module**



**4. Remove Module by releasing  
quick disconnects.**


# LED Module Replacement Instructions



**6. Connect wires of new module with quick wire connects**



**7. Gently place new module into position**



**8. Reattach 3 philips screws**