





WARNINGS:


- Do not assemble continuous run on the ground and lift into place. Joints will distort and not create a tight fit. Joining hardware will have to be purchased and replaced.
- Risk of electrical shock or fire, disconnect power during installation or servicing. Read all instructions completely before starting installation. Install and wire in accordance to all national and local codes by a certified electrician. Fixture may be sharp, handle with care. Let fixture cool before maintenance.

ADVERTENCIA:

Riesgo de descarga eléctrica oun incendio, desconecte la alimentación durante la instalación o servicio. Leer todas las instrucciones completas antes de empesar la instalación. Instalar y cablear en acuerdo a las reglas nacionales y códigos locales por un electricista certificado. El accesorio puede estar agudo, agarre con cuidado deje que el acessorio. Enfriar antes de mantenimiento.

AVERTISSEMENTS:


• Risque d'électrocution ou d'incendie. Déconnectez l'alimentation durant l'installation ou la maintenance. Lisez attentivement toutes les instructions avant de commencer toute installation. Faites installer et câbler selon les normes Nationales et Locales par un électricien certifi é. Les installations peuvent être coupantes, à manipuler avec précaution. Laissez refroidir les installations avant une opération de maintenance.






INSTALLATION AND MOUNTING DETAILS

Inaccessible Ceilings (Sheet Rock Typical)





ROW LAYOUT DETAILS








INSTALLING AN INDIVIDUAL OR ROW-STARTER LUMINAIRE














Connections










Remove Lens or Baffle Assembly with Small Flathead **Screw Driver or Pick**






From Inside Fixture Use Philips Head to Cinch Down Yoke Bracket By Rotating Screw Clockwise





Snap Lens or Baffle Back Into Fixture Aperture




Screws (By Others) Through Flange Holes


Appropriate Tradesman to "Float" Plaster To Finished Edge of Fixture and Paint up to Finished Edge. Energize Fixture and You are Done!





INSTALLING A MID OR ROW-END IN A CONTINU-OUS ROW



Locate Next Fixture In Row, Remove Lens or Baffle Assembly with Small Flathead Screw Driver or Pick








Fixture Must Be Manually Supported During This Step With a Second Set Of Hands For Safety.
Warranty Void if Installed By Single Person
Locate Joining Buckle On First Fixture, And Then Slide


Out Joining Bracket On Second Fixture



NULITE

LM1 Recessed Mud Trim





REPEAT STEPS 8-11

19